

ONEAL

GoPro®

HELMET MOUNT
INCLUDED



Remove the stock original screw on top of the helmet and replace it with the metal screw attached to the GoPro® mount.



Use a screwdriver to turn the screw into the thread of the helmet.



Pay attention that the GoPro® mount is not placed too far towards the back of the helmet. In this position the mount won't fit properly and might rotate while using the GoPro® camera on your helmet.



Use the mount in as close as possible to the position shown in the photo. In this way it will be guided by the visor and won't rotate while using the camera on top of the mount.



Once the GoPro® mount is in the correct position, tighten the screw with a screwdriver.



Double-check the mount is fixed properly. After that you are ready to use your camera with the helmet mount.

O'NEAL

**DESIGNED IN USA
MADE IN CHINA**

O'NEAL USA: O'Neal Distributing, 799 Camarillo Springs Road,
Camarillo, CA 93012 USA

O'NEAL EUROPE: O'Neal Europe GmbH & Co. KG, Erich-Blum-Strasse 33,
71665 Vaihingen/Enz, GERMANY

O'NEAL AUSTRALIA: Cassons Pty Ltd, 2/25 Wonderland Drive,
Eastern Creek, N.S.W., AUSTRALIA 2766

O'NEAL UK: O'Neal UK, PO Box 1237, Bristol, BS48 9DJ, UK